

## CAUTION

### Clamp the Hi-Hat Cable Securely

To prevent the hi-hat cable from being accidentally pulled out, clamp the hi-hat cable as shown in the following illustration.

